



*\* All-thread rods, level adjustment nut+washer, equipment channel, strut by others.*

1. Coordinate location of each AVHM isolator with project submittals.
2. Elevate equipment and pass all-thread rod through equipment mounting hole.
3. Place AVHM isolator through all-thread rod below equipment mounting hole.
4. Secure with level adjustment nut + washer.
5. If necessary, adjust equipment level by the level adjustment nut below the AVHM isolator.

Notes / Remarks :

**VIBRATION MANAGEMENT CORPORATION**

5930 THOMAS ROAD  
HOUSTON - TEXAS 77041 , USA

Internet address:  
[www.vimco.biz](http://www.vimco.biz)

Project :  
Client :  
Consultant :  
Representative:

Title :

**AVHM**  
**Anti-Vibration Hanger Mount**  
**Installation Instructions**

Drawing no.  
**I-230011.01**

Rev. **0**